

ŠKODA

FELICIA *Fun*

FITTING INSTRUCTIONS FOR THE TRUCKMAN TOP

1. SEAL ALL AROUND THE BOTTOM OF THE SECOND 'B' PILLAR USING A CLEAR SILICONE SEALER (NOT SUPPLIED)
2. PLACE THE TRUCKMAN TOP CAREFULLY ONTO THE BACK OF THE PICKUP. ENSURE THAT THE INNER SEAL AT THE FRONT IS TIGHT UP AGAINST THE SECOND 'B' PILLAR.
3. POSITION THE REAR PILLARS SO THAT THERE IS AN EVEN GAP OF APPROX 6MM AROUND THE DOOR. THESE PILLARS CAN BE MOVED INWARDS AND OUTWARDS TO ACHIEVE THIS.
4. ENSURE THAT ALL THE ADJUSTABLE OVERCENTRE CATCHES ARE EXTENDED FULLY DOWNWARDS. THIS CAN BE ACHIEVED BY TURNING THE HOOK ANTI-CLOCKWISE.
5. STARTING WITH THE REAR CATCHES, HANG THE STRIKE FROM THE HOOK AND OPEN THE LATCH SLIGHTLY. MARK THROUGH THE TWO HOLES ON THE STRIKE AND DRILL TO 5MM.
6. USING THE RIVETS SUPPLIED SECURE THE STRIKE TO THE BODY.
7. ADJUST THE LATCH IF NECESSARY TO ENSURE A GOOD TIGHT SEAL.
8. WHEN THE REAR CATCHES ARE FIXED INTO POSITION, CHECK THE OPERATION OF THE BACK DOOR. IF IT IS TIGHT, UNDO THE CATCHES AND PULL THE TOP REARWARDS.
9. REPEAT STEPS 4-6 FOR THE FRONT 2 CATCHES.
10. TAP ONE OF THE 2 SEALS PROVIDED ONTO THE LIP EACH SIDE OF THE TAILBOARD APERTURE WITH THE SOFT RUBBER AGAINST THE TAILBOARD.
11. PLACE THE SELF-ADHESIVE FOAM AGAINST THE BOTTOM EDGE OF THE LOADBED APERTURE TO SEAL AGAINST THE BOTTOM EDGE OF THE TAILBOARD. STEPS 9&10 ARE TO PREVENT FUMES FROM ENTERING THE LOADBED AREA
12. THE TOP IS NOW READY FOR USE.

SHOULD YOU ENCOUNTER ANY PROBLEMS FITTING THIS TOP PLEASE CALL (01242) 580033